

creative vision™ UPDATE INSTRUCTIONS

Version: pcv50_14278_5002_bundleupdate

Since it is highly recommended to “restore the machine to default factory embroidery disk” in order to get full access to all new features, the user should save all personal files and embroideries before performing the update as described below. Personal Files not saved will be lost.

Saving Personal Files and Embroideries on your creative vision



1. Open the Selection Menu
2. Select Files and Folders in the selection bar at the bottom of the screen
3. Use the Folder Structure Arrow Down and select Personal Files
4. Touch each of the files you wish to save
5. Touch Copy
6. Ensure you have inserted your USB Embroidery Stick into your creative vision. Use the Folder Structure Arrow Down and select USB Embroidery Stick
7. Click Paste. A menu with an hour glass and bars opens. This may take some time depending on how many files you have copied. Your files will appear on your screen and are now copied to your stick.

Update

Download the creative vision update
pcv50_14278_5002_bundleupdate.exe

Note: It will also be available through SmartUpdate beginning August 13th.

1. Click the Boot and firmware update program “pcv50_14278_5002_bundleupdate.exe”.
2. Follow the described Boot update quick start guide instructions:
 - a. Connect the sewing machine to the computer with the USB cable.
 - b. To start updating, hold the pattern restart and needle down button, on the front of your creative Vision, simultaneously while clicking the Start update button on your computer.
 - c. When the first part of the boot update is completed, press OK to confirm that the sewing machine has restarted in boot update mode (displayed as headline on the sewing machine screen).
 - d. When the second (last) part of the boot update is completed, verify that the sewing machine has restarted in firmware update mode (on sewing machine screen).
 - e. Close the Boot update application window.



3. The software update program is started automatically when the boot update application is closed. Follow the described software update quick start guide, i.e.

- a. Select advanced options and select restore to default factory embroidery disk. This is important for performance reasons and in order to get full access to all new features (automatic jump stitch cut).



- b. Touch Restore to default factory embroidery disk and Upgrade software version. *Warning: All personal files will be lost.* This is why the files were saved to your embroidery stick prior to the update.



- c. Press Start update.
- d. You will see the progress of your update on your computer screen as well as on your creative vision.
- e. Done. When Finished the screen may go blank for a few seconds. This is normal. Your creative vision will restart automatically. Close the update window. Enjoy!





To Restore your Personal Files

1. Insert your USB Embroidery Stick into your creative vision
2. Open the Selection Menu
3. Select Files and Folders in the selection bar at the bottom of the screen
4. Use the Folder Structure Arrow Down next to Personal Files and select USB Embroidery Stick.
5. Touch each of the files you wish to save
6. Touch Copy
7. Use the Folder Structure Arrow Down next to Personal Files and select Personal Files.
8. Click Paste. A menu with an hour glass and bars opens. This may take some time depending on how many files you have copied. Your files will appear on your screen and are now copied to your Personal Files.